


Article number :
FALN9040L



PARTS LIST(9040L)

*When ordering spare parts, please state item no, part no. and description.

ITEM	PART NO	DESCRIPTION	ITEM	PART NO	DESCRIPTION	ITEM	PART NO	DESCRIPTION
1	HS0530B	HEX.SOC.HD.BOLT	33	OR0319R	O RING	61	11606101	STOPPER
2	SW0500W	SPRING WASHER	34	11003401	TRIGGER VALVE HEAD	62	ER0200H	E RING
3	13900305	CAP	35	11003503	TRIGGER VALVE STEM	63	HS0410B	HEX.SOC.HD.BOLT
4	12100401	SEAL	36	OR2515H	O RING 0250.015	64	HS0516B	HEX.SOC.HD.BOLT
5	12100501	SPRING	37	OR1119R	O RING 0110.020	65	LN0500N	LOCK NUT
6	OR1425R	O RING 0140.025	38	11003803	TRIGGER VALVE GUIDE	66	11106601	COVER
7	11100701	CAP SEAL	39	11006901	SPRING	67	12106401	AIR PLUG
8A	13900801A	PISTON HEAD VALVE ASM.	40A	13904501A	TRIGGER ASSEMBLY	68	OR4030R	O RING 0400.030
8	13900801	PISTON HEAD VALVE	41	HS0406B	HEX.SOC.HD.BOLT	69	12706901	BRACKET
9	OR2435R	O RING 0240.035	42	11604201	NOSE COVER	70	13907001	COLLAR
10	12101001	STOPPER	43	HS0416B	HEX.SOC.HD.BOLT	71	US0506B	UM.HD.BOLT
11	OR3224R	O RING	43-1	SW0400W	SPRING WASHER	72	FW0512W	FLAT.WASHER
13	OR2635R	O RING 0260.035	44	HS0522B	HEX.SOC.HD.BOLT	73	12103301	SEAL
14A	13401401A	DRIVER ASSEMBLY	45	SW0500W	SPRING WASHER	74	13907403	EXHAUST COVER
18	OR4630R	O RING 0460.035	46	12504601	NOSE			
19	13301901	CYLINDER	47	11304701	SET PLATE			
19-1	13901903	COLLAR	48	12504801	SET PLATE			
20	13902001	BUMPER	49A	12504901A	STAPLE GUIDE UNIT			
21	OR3520R	O RING 0350.020	50	12505001	MAGAZINE			
22	OR3635R	O RING 0360.035	51	12505101	PUSHER			
23	13902301	BODY	52	11205201	SLIDE BLOCK			
24	OR1919H	O RING 0190.020	53	11305301	SPRING			
25	12502501	JOINT GUIDE	54	11305401	ROD			
26	11002601	SPRING	55	11305501	SHAFT			
27	11002701	GUIDE SAFETY LEVER	56	11305601	SET BLOCK			
29	LN0300N	LOCK NUT	57	11605701	STEPPED PIN			
30	CH0308B	CAP.HD.SCREW	58	12505801	END CORE			
31	12703101	SAFETY LEVER	59	US0510B	UM.HD.BOLT			
32	12103202	STEPPED PIN	60	11306001	TOR. SPRING			