



Pos	Description	Art.code
1	Hex.Soc.Hd.Bolt	FXW32206140766
2	Bushing,Deflector	FXW20790000001
3	Deflector,Exhaust	FXW20790010115
4	Hex.Soc.Hd.Bolt	FXW30106250866
5	Cap	FXW207900202XX
6	Piston Stopper	FXW20750140217
7	Head Valve Spring	FXW20970160100
8	O-Ring	FXW30700110000
9	O-Ring	FXW30700111000
10	Piston Head Valve	FXW20750150000
11	Cylinder Seal	FXW20790180116
12	O-Ring	FXW30700112000
13	O-Ring	FXW30700113000
14	Cylinder Spacer	FXW20750370000
15	O-Ring	FXW30700121000
16A	Driver Assembly	FXW20790461001
17	Seal	FXW20750250117
18	O-Ring	FXW30700075000
19	Cylinder	FXW20790350000
20	Bumper	FXW20750470115
21	Driver Guide	FXW20790480001
22	Gasket,Cap	FXW20750130015
23A	Body Assembly	FXW207506023XX
24	O-Ring	FXW30700185000
25	End Cap	FXW207707X02XX
26	O-Ring	FXW30700079000
27	O-Ring	FXW30700081000
28	Valve	FXW20770900016
29	O-Ring	FXW30700002000
30	O-Ring	FXW30700201000
31	O-Ring	FXW30700071000
32	Valve Plunger	FXW20770910016
33	Spring	FXW20770960001
34	O-Ring	FXW30700080000
35	Plunger	FXW22220920100
36	Plunger Cap	FXW20770930016
37A	Trigger Assembly	FXW22220952215
38	Spring Pin	FXW30803240001
39	Grommet	FXW30700078000
40	Trigger Pin	FXW20770890101
41	Guide, Contact Trip	FXW22222840115
42	Spring , Safety	FXW20791490001
43A	Upper Safety Lever Assem- bly	FXW22241482001
44	Hex.Soc.Hd.Bolt	FXW30104100166
45	Locknut	FXW30604070066

Pos	Description	Art.code
46	Gasket	FXW20011070000
47	Bottom	FXW20111080166
48	Hex.Soc.Hd.Bolt	FXW30106200866
49	Spring Pin	FXW32304240001
50	Nose	FXW20791350066
51	Door	FXW20791340066
52	Spring Pin	FXW30804160001
53A	Latch Door Assmly	FXW20791361066
54	Hex.Soc.Hd.Bolt	FXW30503060166
55	Steel	FXW20791440000
56A	Lower Safety Lever Assem- bly	FXW20791511001
57	Safety Cover	FXW20791520001
58	Hex.Soc.Hd.Bolt	FXW30105080266
59	Pusher	FXW20792130001
60	Latch	FXW20792360115
61	Spiral Spring	FXW20792090100
62	Roller	FXW20792110016
63	Roller Pin	FXW32104198012
64	Hex.Soc.Hd.Bolt	FXW30105300866
65	Magzine	FXW20792050115
66	Magzine Cap	FXW20792180215
67	Hex.Soc.Hd.Bolt	FXW30105180166
68	Locknut	FXW30605080001
69	Bracket	FXW20792170001
70	Hex.Soc.Hd.Bolt	FXW30106220166
71	Flat Washer	FXW30900002001
72	Locknut	FXW30606100001
73	Spring	FXW20792620001
74	Spring	FXW20792290001
Optional Parts		
75A	Belt Hook Assembly	FXW20970832515
75A-1	End Cap	FXW209707X03XX
75A-2	Belt Hook	FXW20970830115
75A-3	O-Ring	FXW30700188000
75A-4	Cover Belt Hook	FXW20970840001
75A-5	C-Ring	FXW33425000001