



Pos	Description	Art.code
1	Hex. Soc. Hd. Bolt	FXW30105140766
2	Bushing	FXW20790000001
3	Deflector	FXW20790010115
4	Hex. Soc. Hd. Bolt	FXW31605220766
5	Cap	FXW216000201XX
6	Metal Shim	FXW21180230001
7	Piston Stopper	FXW21570140117
8	Spring	FXW20970160100
9	O-Ring	FXW30700110000
10	O-Ring	FXW30700111000
11	Piston, Head Valve	FXW21970150000
12	Cap, Gasket	FXW21570130000
13	Seal	FXW21570250017
14	O-Ring	FXW30700153000
15	Cylinder Spacer	FXW21570370016
16	O-Ring	FXW30700042000
17	O-Ring	FXW30700169000
18	Cylinder	FXW21600350000
19	O-Ring	FXW30700108000
20	O-Ring	FXW21570510015
21A	Driver Assembly	FXW21600462401
22	Bumper	FXW21570470015
23	Driver Guide	FXW21570480001
24A	Body Assembly	FXW215706022XX
25	O-Ring	FXW30700185000
26	End Cap	FXW207707X02XX
27	O-Ring	FXW30700079000
28	O-Ring	FXW30700081000
29	Valve	FXW20750900074
30	O-Ring	FXW30700002000
31	O-Ring	FXW30700024000
32	O-Ring	FXW30700071000
33	Valve Plunger	FXW20750910074
34	Spring	FXW20770960001
35	O-Ring	FXW30700080000
36	Plunger	FXW22209201000
37	Plunger Cap	FXW20770930016
38A	Trigger Assembly-Bump	FXW20750952115
39	Spring Pin	FXW30803240001
40	Trigger Pin	FXW20770890101
41	Grommet	FXW30700078000
42	Guide Contact Trip	FXW21572840015
43	Upper Safety Lever	FXW21601480001
44A	Adjusting Nut Assembly	FXW21601901115
45	Lower Safety	FXW21601680001
46	E-Ring	FXW31302500001

Pos	Description	Art.code
47	Spring, Safety	FXW21571490001
48	Bushing	FXW21571470001
49	Safety Cover	FXW21601550015
50	Hex. Soc. Hd. Bolt	FXW31605120766
51	Nose	FXW21601350166
52	Hex. Soc. Hd. Bolt	FXW30105120166
53	Driver Guide Cover	FXW21571330066
54	Roll Pin	FXW21341170101
55	Door	FXW21601340166
56	Latch Door Pin	FXW21823620001
57A	Latch Door Assembly	FXW21571361001
58	Latch Door, Cover	FXW21571380015
59	Hex. Soc. Hd. Bolt	FXW30105300866
60	Magazine Cap	FXW21572180015
61	Magazine	FXW21602050015
62	Hex. Soc. Hd. Bolt	FXW31605100766
63	Pusher	FXW21572130001
64	Latch	FXW20792360115
65	Spring	FXW20792290001
66	Spiral Spring	FXW20792090100
67	Roller	FXW20792110016
68	Roller Pin	FXW32104198012
69	Bracket	FXW21602170001
70	Spring	FXW20792620001
71	Flat Washer	FXW30900005001
72	Hex. Soc. Hd. Bolt	FXW30105140166
73	Locknut	FXW30605080001
74	O-Ring	FXW30700157000
Optional Parts		
75A	Belt Hook Assembly	FXW20970832515
75A-1	End Cap	FXW209707X03XX
75A-2	Belt Hook	FXW20970830115
75A-3	O-Ring	FXW30700188000
75A-4	Cover Belt Hook	FXW20970840001
75A-5	C-Ring	FXW33425000001
76A	Trigger Assembly-Seq.	FXW20770952259