



Pos	Description	Art.code
1	Hex.Soc.Hd.Bolt	FXW30105140766
2	Bushing,Deflector	FXW20790000001
3	Deflector,Exhaust	FXW20790010115
4	Hex.Soc.Hd.Bolt	FXW31605220766
5	Cap	FXW215700202XX
6	Metal Shim	FXW21180230001
7	Piston Stopper	FXW21570140117
8	Head Valve Spring	FXW20970160100
9	O-Ring	FXW30700110000
10	O-Ring	FXW30700111000
11	Piston Head Valve	FXW21970150000
12	Cap, Gasket	FXW21570130000
13	Seal	FXW21570250017
14	O-Ring	FXW30700153000
15	Cylinder Spacer	FXW21570370016
16	O-Ring	FXW30700042000
17	O-Ring	FXW30700169000
18	Cylinder	FXW21570350000
19	O-Ring	FXW30700108000
20	O-Ring	FXW21570510015
21A	Driver Assembly	FXW22050462101
22	Bumper	FXW21570470015
23	Driver Guide	FXW22050480101
24A	Body Assembly	FXW215706022XX
25	O-Ring	FXW30700185000
26	End Cap	FXW207707X02XX
27	O-Ring	FXW30700079000
28	O-Ring	FXW30700081000
29	Valve	FXW20770900016
30	O-Ring	FXW30700002000
31	O-Ring	FXW30700201000
32	O-Ring	FXW30700071000
33	Valve Plunger	FXW20770910016
34	Spring	FXW20770960001
35	O-Ring	FXW30700080000
36	Plunger	FXW22220920100
37	Plunger Cap	FXW20770930016
38A	Trigger Assembly	FXW22220952215
39	Spring Pin	FXW30803240001
40	Trigger Pin	FXW20770890101
41	Grommet	FXW30700078000
42	Guide, Contact Trip	FXW22012840015
43	Upper Safety Lever	FXW22011480001
44	Adjusting Nut	FXW22011600001
45	Adjusting Spring	FXW20771630001
46	Adjusting Post	FXW22011500001

Pos	Description	Art.code
47	Ball,Steel	FXW31200200000
48	Loewr Safety	FXW22021510001
49	E-ring	FXW31303000001
50	Spring,Safety	FXW20771490001
51	Safety Cover	FXW22021580015
52	NOSE	FXW22051350066
53	Upper Door	FXW22011330066
54	Pin	FXW21221170001
55	Door	FXW22021340066
56A	Latch Door Assembly	FXW22021361001
57	Spring Pin	FXW30803160001
58	Hex.Soc.Hd.Bolt	FXW30105300866
59	Magzine Cap	FXW21442180215
60	Hex.Soc.Hd.Bolt	FXW30105250266
61	Magzine	FXW22052050001
62	Bracket	FXW22052170001
63	Spring	FXW22022620100
64	Hex.Soc.Hd.Bolt	FXW31605120766
65	Pusher	FXW22052130101
66	Latch	FXW20792360115
67	Spring	FXW20792290001
68	Spiral Spring	FXW21442090000
69	Roller	FXW21442110016
70	Roller Pin	FXW32104198012
71	Flat Washer	FXW30900005001
72	Hex.Soc.Hd.Bolt	FXW30105140166
73	Locknut	FXW30605080001
74	O-Ring	FXW30700136000
75	O-Ring	FXW30700157000
76	Hex.Soc.Hd.Bolt	FXW30104060166
<b>Optional Parts</b>		
77A	Belt hook Assembly	FXW20970832515
77A-1	End Cap	FXW209707X03XX
77A-2	Belt hook	FXW20970830115
77A-3	O-Ring	FXW30700188000
77A-4	Cover,Belt hook	FXW20970840001
77A-5	C-ring	FXW33425000001