



| Pos | Description | Art.code |
|-----|---------------------|----------------|
| 1 | Hex.Soc.Hd.Bolt | FXW30105140766 |
| 2 | Bushing,Deflector | FXW20790000001 |
| 3 | Deflector | FXW20790010115 |
| 4 | Hex.Soc.Hd.Bolt | FXW31605220766 |
| 5 | Cap | FXW215700202XX |
| 6 | Metal Shim | FXW21180230001 |
| 7 | Piston Stopper | FXW21570140117 |
| 8 | Head Valve Spring | FXW20970160100 |
| 9 | O-Ring | FXW30700110000 |
| 10 | O-Ring | FXW30700111000 |
| 11 | Piston Head Valve | FXW21970150000 |
| 12 | Cap, Gasket | FXW21570130000 |
| 13 | Seal | FXW21570250017 |
| 14 | O-Ring | FXW30700153000 |
| 15 | Cylinder Spacer | FXW21570370016 |
| 16 | O-Ring | FXW30700042000 |
| 17 | O-Ring | FXW30700169000 |
| 18 | Cylinder | FXW21570350000 |
| 19 | O-Ring | FXW30700108000 |
| 20 | O-Ring | FXW21570510015 |
| 21A | Driver Assembly | FXW22020462201 |
| 22 | Bumper | FXW21570470015 |
| 23 | Driver Guide | FXW22050480101 |
| 24A | Body Assembly | FXW215706022XX |
| 25 | O-Ring | FXW30700185000 |
| 26 | End Cap | FXW207707X02XX |
| 27 | O-Ring | FXW30700079000 |
| 28 | O-Ring | FXW30700081000 |
| 29 | Valve | FXW20770900016 |
| 30 | O-Ring | FXW30700002000 |
| 31 | O-Ring | FXW30700201000 |
| 32 | O-Ring | FXW30700071000 |
| 33 | Valve Plunger | FXW20770910016 |
| 34 | Spring | FXW20770960001 |
| 35 | O-Ring | FXW30700080000 |
| 36 | Plunger | FXW22220920100 |
| 37 | Plunger Cap | FXW20770930016 |
| 38A | Trigger Assembly | FXW22220952215 |
| 39 | Spring Pin | FXW30803240001 |
| 40 | Trigger Pin | FXW20770890101 |
| 41 | Grommet | FXW30700078000 |
| 42 | Guide, Contact Trip | FXW22012840015 |
| 43 | Upper Safety Lever | FXW22011480001 |
| 44 | Adjusting Nut | FXW22011600001 |
| 45 | Adjusting Spring | FXW20771630001 |
| 46 | Adjusting Post | FXW22011500001 |

| Pos | Description | Art.code |
|-----------------------|---------------------|----------------|
| 47 | Ball,Steel | FXW31200200000 |
| 48 | Loewr Safety | FXW22021510001 |
| 49 | E-ring | FXW31303000001 |
| 50 | Spring,Safety | FXW20771490001 |
| 51 | Safety Cover | FXW22021580015 |
| 52 | NOSE | FXW22021350266 |
| 53 | Upper Door | FXW22011330166 |
| 54 | Pin | FXW21221170001 |
| 55 | Door | FXW22021340066 |
| 56A | Latch Door Assembly | FXW22021361001 |
| 57 | Spring Pin | FXW30803160001 |
| 58 | Hex.Soc.Hd.Bolt | FXW30105300866 |
| 59 | Magzine Cap | FXW21442180315 |
| 60 | Hex.Soc.Hd.Bolt | FXW30105220266 |
| 61 | Magzine | FXW22022050101 |
| 62 | Bracket | FXW22022170001 |
| 63 | Spring | FXW22022620100 |
| 64 | Hex.Soc.Hd.Bolt | FXW31605100766 |
| 65 | Pusher | FXW22022130101 |
| 66 | Latch | FXW20792360115 |
| 67 | Spring | FXW20792290001 |
| 68 | Spiral Spring | FXW21442090000 |
| 69 | Roller | FXW21442110016 |
| 70 | Roller Pin | FXW32104198012 |
| 71 | Flat Washer | FXW30900005001 |
| 72 | Hex.Soc.Hd.Bolt | FXW30105140166 |
| 73 | Locknut | FXW30605080001 |
| 74 | O-Ring | FXW30700136000 |
| 75 | O-Ring | FXW30700157000 |
| 76 | Hex.Soc.Hd.Bolt | FXW30104040166 |
| Optional Parts | | |
| 77A | Belt hook Assembly | FXW20970832515 |
| 77A-1 | End Cap | FXW209707X03XX |
| 77A-2 | Belt hook | FXW20970830115 |
| 77A-3 | O-Ring | FXW30700188000 |
| 77A-4 | Cover,Belt hook | FXW20970840001 |
| 77A-5 | C-ring | FXW33425000001 |