



Pos	Description	Art.code
1	Hex.Soc.Hd.Bolt	FXW30104080566
2	Bushing	FXW21030000001
3	Hex.Soc.Hd.Bolt	FXW30104200566
4	Deflector, Exhaust	FXW21030010015
5	Cap	FXW210400203XX
6	Casket, Cap	FXW21030130000
7	Seal	FXW21030190017
8	O-Ring	FXW30700123000
9	Piston Stopper	FXW21030140016
10	O-Ring	FXW30700125000
11	O-Ring	FXW30700120000
12	Spring	FXW21030160000
13	VALVE, HEAD	FXW21030150216
14	O-Ring	FXW30700126000
15	Cylinder Spacer	FXW21030340116
16	O-Ring	FXW30700044000
17	O-RING	FXW30700187000
18A	Driver Assembly	FXW21040461400
19	Cylinder	FXW21040350200
20	Bumper	FXW21030470115
21	Driver Guide	FXW21030480101
22A	Body Assembly	FXW208006025XX
23	O-Ring	FXW30700185000
24	End Cap	FXW207707X04XX
25	O-Ring	FXW30700079000
26	O-Ring	FXW30700081000
27	Valve	FXW20770900016
28	O-Ring	FXW30700002000
29	O-Ring	FXW30700201000
30	O-Ring	FXW30700071000
31	Valve Plunger	FXW20770910016
32	Spring	FXW20770960001
33	O-Ring	FXW30700080000
34	Plunger	FXW22220920100
35	Plunger Cap	FXW20770930016
36A	Trigger Assembly	FXW22220952315
37	Spring Pin	FXW30803240001
38	Pin Trigger	FXW20460890001
39	Grommet	FXW30700078000
40	Guide, Contact Trip	FXW22282840215
41	Spring, Safety	FXW21031490101
42	E-ring	FXW31303000001
43	Adjusting Nut	FXW20801600001
44	Adjusting Spring	FXW20771630001
45	Ball,Steel	FXW31200200000
46	Adjusting Post	FXW21031500066

Pos	Description	Art.code
47	Contact Trip , Upper	FXW22281480001
48	Lower Safety Lever Assembly	FXW22071510166
49	Rubber Pad	FXW21481580015
50A	SA, Door Latch	FXW21041362266
51	Lower Door, Machined	FXW21041340466
52	Spring Pin	FXW30803165001
53	Nose, Machined	FXW21041350366
54	Spring Pin	FXW30804160001
55	Spring Stopper	FXW20142230001
56	Hex.Soc.Hd.Bolt	FXW30104060166
57	Pusher	FXW21042130001
58	Spring Lock	FXW20252240016
59	Spring	FXW20142210001
60	Magazine Cover	FXW21042200206
61	Magazine	FXW21042050206
62	Nail Guide Liner	FXW21032060001
63	Magazine Cap	FXW21042180015
64	Spring Pin	FXW30803100001
65	Latch	FXW20032280066
66	Spring	FXW20032330001
67	Hex.Soc.Hd.Bolt	FXW30104160166
68	Locknut	FXW30604070066
69	Magazine Cover Stopper	FXW20162220101
70	Hex.Soc.Hd.Bolt	FXW30104080266
71	Hex.Soc.Hd.Bolt	FXW30104180166
72	Bracket	FXW21042170066
73	Hex.Soc.Hd.Bolt	FXW30505100166
74	Flat Washer	FXW30900010001
<b>Optional parts</b>		
75A	Belt Hook Assembly	FXW20970832515
75A-1	End Cap	FXW209707X03XX
75A-2	Belt Hook	FXW20970830115
75A-3	O-Ring	FXW30700188000
75A-4	Cover Belt Hook	FXW20970840101
75A-5	C-Ring	FXW33425000001