



Pos	Description	Art.code
1	Hex. Soc. Hd. Bolt	FXW30104080466
2	Bushing,Deflector	FXW21030000001
3	Hex. Soc. Hd. Bolt	FXW30104200566
4	Deflector,Exhaust	FXW21030010015
5	Cap,Machined	FXW214600200XX
6	Gasket, Cap	FXW21030130000
7	Seal	FXW21030190017
8	O-Ring	FXW30700123000
9	Piston Stopper	FXW21030140016
10	O-Ring	FXW30700125000
11	O-Ring	FXW30700120000
12	Spring	FXW21030160000
13A	Piston Head Valve Assy.	FXW21030151316
14	Cylinder Spacer	FXW21030340116
15	O-Ring	FXW30700044000
16	O-Ring	FXW30700119000
17A	Driver Assy.(one piece)	FXW21460572201
18	O-Ring	FXW30700013000
19	Cylinder	FXW21460350000
20	Bumper	FXW21030470115
21	Driver Guide	FXW21030480101
22A	Body Assembly	FXW208006025XX
23	O-Ring	FXW30700185000
25	End Cap	FXW207707X04XX
25	O-Ring	FXW30700079000
26	O-Ring	FXW30700081000
27	Valve	FXW20770900016
28	O-Ring	FXW30700002000
29	O-Ring	FXW30700201000
30	O-Ring	FXW30700071000
31	Valve Plunger	FXW20770910016
32	Spring	FXW20770960001
33	O-Ring	FXW30700080000
34	Plunger	FXW22220920100
35	Plunger Cap	FXW20770930016
36A	Trigger Assembly	FXW22320952115
37	Spring Pin	FXW30803240001
38	Pin Trigger	FXW20460890001
39	Grommet	FXW30700078000
40	Guide, Contact Trip	FXW22282840215
41	Spring, Safety	FXW21721490001
42	E-Ring	FXW31303000001
43	Adjusting Nut	FXW20801600001
44	Ball, Steel	FXW31200200000
45	Adjusting Post	FXW20801500101
46	Adjusting Spring	FXW20771630001

Pos	Description	Art.code
47	Contact Trip, Upper	FXW22281480001
48A	SA, Door Latch	FXW22941361201
49	Door Spacer	FXW21801410001
50A	Safety Lever Assy.	FXW21801341301
51	Nose	FXW21801350366
52A	Magazine Assembly	FXW21462052006
53	Hex. Soc. Hd. Bolt	FXW30505100166
54	Rubber Pad	FXW21461580015
55A	Pusher Assembly	FXW21802131201
56	Spring Lock	FXW21802940216
57	Spring	FXW21802210001
58	Pin	FXW30803100001
59	Magazine Cover	FXW21802200206
60	Spring	FXW21702330001
61	Latch	FXW20032280066
62	Magazine Cap	FXW21462180015
63	Hex. Soc. Hd. Bolt	FXW30104160166
64	Locknut	FXW30604070066
65	Magazine Cover Stopper	FXW20032220001
66	Bracket	FXW21462170066
67	Hex. Soc. Hd. Bolt	FXW30104180166
68	Flat Washer	FXW30900010001
69	Hex. Soc. Hd. Bolt	FXW30104080266
70	Spring Pin	FXW30803300001
71	Spring Pin	FXW30803180001
72	O-Ring	FXW30700136000
73	Latch Cap	FXW22943690215
Optional parts		
74A	Belt Hook Assembly	FXW20970832515
74A-1	End Cap	FXW209707X03XX
74A-2	Belt Hook	FXW20970830115
74A-3	O-Ring	FXW30700188000
74A-4	Cover Belt Hook	FXW20970840101
74A-5	C-Ring	FXW33425000001